



**EPOXY RESIN PRIMER SUPPLIED IN PRE-DOSED KITS
TO BE INSTALLED ON SLEEVE TYPE “MZA”**

INSTALLATION INSTRUCTIONS

THE KIT CONTAINS:

- ONE WHITE SEALED “EASY-OPEN” CAN WITH 125 GR. OF RESIN (PART “A”)
- ONE ORANGE SEALED “EASY-OPEN” CAN WITH 25 GR. OF RESIN (PART “B”)

**NOTE: KITS ARE STENCILLED WITH CODE NUMBER, EXPIRY DATE AND HAZARDOUS MATERIALS CODE
(CONSULT MATERIAL SAFETY DATA SHEET)**

1 – WEAR THE PROTECTIVE GLOVES SUPPLIED WITH THE KIT

2 – OPEN THE PRE-DOSED CANS

3 – POUR PART “B” (ORANGE COLOR) INTO PART “A” (WHITE COLOR) AND MIX CAREFULLY USING THE STICK SUPPLIED WITH THE KIT.

4 – POUR THE MIXTURE ON THE TOP OF THE HEATED AND SHOT-BLASTED PIPE AND SMEAR OVER THE ENTIRE STEEL SURFACE USING THE APPLICATOR PAD SUPPLIED WITH THE KIT. DO NOT PAINT THE MILL COATING ON THE PIPE

5 –INSTALL THE SLEEVE USING THE STANDARD PROCEDURE

ATTENTION: HARDENING TIME OF THE COMPOUND (“SHELF LIFE”) IS APPROX. 1 HR. AT +23°C, 18 MINUTES AT +40°C AND 6 MINUTES AT +60°C.

ATTACHED: PICTURE OF THE KIT COMPONENTS

zanelli - picture no. 1
epoxy primer - content of the kit

