

INSTALLATION INSTRUCTIONS FOR THE SLEEVE TYPE "MZV"


Grit-blat the steel surface by projection of selected abrading materials to obtain a finishing standard $Sa\ 2\frac{1}{2}$ according to ISO 8501-1, or by mechanical grinding to St. 3.
Clean the steel surface from residual abrading material.




Smooth by hand-grinder surface irregularities as arc-burns etc.




Bevel the mill-coating edge with an angle of approx. 30°



Heat the steel surface and the adjacent overlap area of the mill-coating with propane torch (strong flame). In case of pipe size over 14" is recommended to operate with two workers.
Reach the uniform temperature of 60°C minimum.




Unroll the sleeve and wrap over the pipe. Overlap the edges by approx. 10 cm. Be careful not to dirty the sleeve with contaminating materials as dust, sand etc. Peel-off the protective foil when wrapping the sleeve.




ZANELLI COMMERCIALE s.r.l.

ZANELLI s.r.l.

Activate sealpatch adhesive by gently heating the adhesivised side with the flame. Position and apply the sealpatch in the center part of the sleeve edge. Heat strongly and press on the entire lenght with gloved hand to assure good bonding.




Start to shrink the sleeve by heating from the central part and proceeding toward right and left side following the visible shrinkage of the material. Keep massaging the sleeve with gloved hand during the shrinkage to assist the expulsion of any intrapped air.



Roll (optional) the overlap area, sealpatch area and mill-coating overlap area. Heat gently during rolling to keep adhesive fluid and workable. The coming-our of some adhesive from the edge of the sleeve proof the good execution of the installation.



Section of the coated joint showing the overlap area and the sealpatch.



ZANELLI s.r.l.

Via Proventa 150/6 • 48018 Faenza (RA) - Italy • P.O. Box 175 • Tel. +39 (0) 546 46559 • Fax +39 (0) 546 636202

ZANELLI COMMERCIALE s.r.l.

Sede legale: Via Banaffa, 55/A • Sede Operativa: Via Banaffa 54 • Magazzino: Via Proventa, 150/6 • 48018 Faenza (RA) - Italy
P.O. Box 175 • Tel +39 (0) 546 634037 • Fax +39 (0) 546 634031 • E-mail: zanellisrl@mbox.dinamica.it • www.zanelli.it